



JIB FURLING **FITTING INSTRUCTIONS**

The Barton furling gear is available in two sizes for use on jibs fitted to Dinghies, Catamarans and day boats. Furling drum part no 42334 for maximum sail area up to 60 sq ft (5.74 sq m) or Furling drum part no 42335 for maximum sail area up to 100 sq ft (9.29 sq m). Both sizes use Top swivel part no 42336.



The jib requires a fixed wire luff and two attachment points at the bow, one for the forestay and one for the furling drum, separated enough that they do not touch. Attach

the furling drum to the attachment point and then secure the jib tack to the top plate on the furling drum, attach the head of the sail into the top swivel forks and then secure the halyard to the top swivel with a shackle. Hoist the sail and tension the luff. When the sail is being furled, the sail head will rotate and may come into contact with the forestay if too close, to prevent this from happening a round thin Perspex (or any other Non corroding material) spacer disc can be inserted between the swivel and the shackle, this will prevent the two coming into contact.




Now attach the jib sheet and wind the Furling drum by hand anticlockwise until the sail is completely furled, continue to furl until the jib sheets have wrapped around the jib twice. Now attach a 5mm line up through the hole in the top of the furling drum and tie off using a stopper knot, and then thread the rest of the line back through the stainless steel eye of the furler and back to the cleat in the cockpit. We would recommend fitting a bullseye to the deck approx 30cm aft of the furler to ensure the furling line is kept low to the deck and to ensure the line does not interfere with the jib and the correct lead is maintained to the cockpit.

Correct furling line length =

Distance between the furler and the cleat + the jib sail foot length + length of tail in the cockpit

With the line now threaded from the furler through the cleat place the remaining line on the cockpit floor. You are now ready to unfurl your jib by pulling on your sheets, as the jib unfurls your furling drum should fill with the furling line, with the jib completely unfurled the drum should be full of line. The length of the tail can now be

adjusted by cutting to length. Now by pulling on the furling line the jib Luff will rotate and furl the sail. Repeat furling and unfurling the sail several times to ensure the furled jib does not come into contact with the forestay. (Increase dia of the disc if problem arises)



Safety: Never set a sail whilst the craft is out of the water. When at dockside only unfurl the jib when the conditions allow, ensuring that the craft is securely tied.

A large range of marine hardware for yachts up to 50ft is detailed in our catalogue, available on request or visit our website www.bartonmarine.com

Barton
MARINE
control the power